

Production Process Support Software for Pokayoke Tools



INSTRUCTION MANUAL V3.10

Please use this Instruction manual correctly on reading well.

Please keep it carefully to be able to read immediately, when required.



Before using

Thank you for purchasing the product.

Please read this Instruction Manual carefully and use this product correctly.

After reading the Instruction Manual, keep it handy and refer to it at any time when needed.

This product is protected by laws and international treaties on copyright.

Please note that reproduction of all or part of this product or distribution of copies without permission violates copyright.

Be sure to read the license agreement of "POKAYOKE plus" in this document.

"POKAYOKE plus" END USER LICENSE AGREEMENT

IMPORTANT: PLEASE READ THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT ("LICENSE AGREEMENT") CAREFULLY BEFORE USING THE SOFTWARE (AS DEFINED BELOW). HERUTU ELECTRONICS CORPORATION IS WILLING TO LICENSE THE SOFTWARE TO YOU AS THE INDIVIDUAL, THE COMPANY, OR THE LEGAL ENTITY THAT WILL BE UTILIZING THE SOFTWARE (REFERENCED BELOW AS "YOU" OR "YOUR") ONLY ON THE CONDITION THAT YOU ACCEPT ALL OF THE TERMS OF THIS LICENSE AGREEMENT. THIS IS A LEGAL AND ENFORCEABLE CONTRACT BETWEEN YOU AND HERUTU ELECTRONICS CORPORATION. BY CLICKING THE "I AGREE" OR "YES" BUTTON OR OTHERWISE INDICATING ASSENT ELECTRONICALLY, OR LOADING THE SOFTWARE, YOU AGREE TO THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. IF YOU DO NOT AGREE TO THESE TERMS AND CONDITIONS, CLICK THE "CANCEL" OR "NO" OR "CLOSE WINDOW" BUTTON OR OTHERWISE INDICATE REFUSAL, MAKE NO FURTHER USE OF THE SOFTWARE.

1. License:

The software (including any accompanying features) and documentation (including any product packaging) (the "Documentation"), that accompanies this License Agreement (collectively the "Software") is the property of HERUTU ELECTRONICS CORPORATION, and is protected by copyright law. Although HERUTU ELECTRONICS CORPORATION continues to own the Software, after Your acceptance of this License Agreement You will have certain rights to use the Software. This License Agreement governs any releases, revisions, updates or enhancements to the Software that HERUTU ELECTRONICS CORPORATION may make available to You. Your rights and obligations under this License Agreement with respect to the use of this Software are as follows.

- a. use one copy of the Software on a single computer;
- b. use the Software in accordance with any additional permitted uses which may be set forth below;

You may not, nor may you permit any other person to:

- a. reproduce, sublicense, rent, lease, resell or distribute any portion of the Software;
- b. reverse engineer, decompile, disassemble, modify, change, translate, make any attempt to discover the source code of the Software or create derivative works from the Software:
- c. use the Software in any manner that is not permitted pursuant to this License Agreement;

2. Software Feature Updates:

You shall have the right to receive new features to the Software as HERUTU ELECTRONICS CORPORATION, in its sole discretion, makes such features available with the Software. HERUTU ELECTRONICS CORPORATION continually strives to improve the usability and performance of its products and services. In order to optimize the Software, HERUTU ELECTRONICS CORPORATION may, at its discretion and without notice, add, modify or remove features from the Software at any time.

3. Warranty:

TO THE EXTENT ALLOWED BY LAW, THE SOFTWARE IS PROVIDED TO YOU "AS IS" WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. HERUTU ELECTRONICS CORPORATION SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABLITY, SATISFACTORY QUALITY, NON-INFRINGEMENT AND/OR FITNESS FOR A PARTICULAR PURPOSE.

4. Limitation of Liability:

IN NO EVENT SHALL HERUTU ELECTRONICS CORPORATION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INDIRECT, OR SIMILAR DAMAGES, INCLUDING ANY LOST PROFITS OR LOST DATA ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE EVEN IF HERUTU ELECTRONICS CORPORATION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

EXCEPT FOR DAMAGES INCURRED BY YOU ARISING FROM INTENTIONAL ACT OR GROSS NEGLIGENCE SOLELY ON THE PART OF HERUTU ELECTRONICS CORPORATION, IN NO CASE SHALL HERUTU ELECTRONICS CORPORATION'S LIABILITY EXCEED THE PURCHASE PRICE WHICH YOU PAID. The disclaimers and limitations set forth above shall apply regardless of whether You accept the Software.

5. Governing Laws:

This License Agreement shall be governed by the laws of Japan, and the Shizuoka District Court shall have exclusive primary jurisdiction with respect to all disputes arising with respect thereto.

6. General:

This License Agreement is the entire agreement between You and HERUTU ELECTRONICS CORPORATION relating to the Software and: (i) supersedes all prior or contemporaneous oral or written communications, proposals, and representations with respect to its subject matter; and (ii) prevails over any conflicting or additional terms of any quote, order, acknowledgment, or similar communications between the parties. Notwithstanding the foregoing, nothing in this License Agreement shall diminish any rights You may have under existing consumer protection legislation or other applicable laws in Your jurisdiction that may not be waived by contract. This License Agreement shall terminate upon Your breach of any term contained in this License Agreement

and You shall cease use of and destroy all copies of the Software and Documentation. The disclaimers of warranties and damages and limitations on liability shall survive termination. This License Agreement may only be modified by the Documentation or by a written document that has been signed by both You and HERUTU ELECTRONICS CORPORATION. Should You have any questions concerning this License Agreement, or if You desire to contact HERUTU ELECTRONICS CORPORATION for any reason, please visit the HERUTU ELECTRONICS CORPORATION's homepage at https://www.herutu.co.jp/en/.

Table of Contents

1. Introduction	
1-1. Overview	1
1-2. System Requirements	7
1-3. Supported Devices	7
2. Mouting Method	9
2-1. Equipment configuration	9
2-2. Network Settings	9
2-3. Selection of Operating Mode	9
2-4. Setting the receiver data type	9
3. POKAYOKE plus	10
3-1. Installation	10
3-2. Screen Configuration	12
3-3. Menu Configuration	13
3-4. Flow of setting and operating POKAYOKE plus	14
3-5. POKAYOKE plus Start up	15
3-6. Default Settings	15
3-7. Recever Registration	24
3-8. I/O unit Registration	27
3-9. Tool Registration	30
3-10. Work Registration and Start	36
3-11. Work Sequence Registration and Start	48
3-12. Registration of safety protector group and Start of monitoring	53
3-13. Work Execution Status Screen	59
3-14. Work Execution Screen	62
3-15. Safety protectors wearing status screen	67
3-16. History	70
3-17. Transmission of error information to smartphones or other devices in	real time(MQTT
output)	77
3-18. Specifications for external device interface	79
3-19. Error Code	81
3-20. Product Information	81
3-21. Exit POKAYOKE plus	82
4. Actions When Receiver TW-800R-SCL Is Used	83
5. POKAYOKE plus Viewer	88
6. Troubleshooting	89

1. Introduction

1-1. Overview

Explanation of terms

Term	Description		
Tool	Tools or safety protectors with POKAYOKE transmitter "TW-800T"," HRF-		
	2402", etc. installed.		
Receiver	Our POKAYOKE receiver with LAN connection.		
	A device for receiving the signal wirelessly transmitted from the transmitter		
	attached to the tool and transmitting the signal to the external device being		
	connected via LAN.		
	Compatible models:		
	(1) Simple Pokayoke Counter TW-800R-SCL		
	(2) LAN Connection Type Pokayoke Receiver TW-800R-EXL / TW-820R-		
	EXL(hereinafter called "TW-8##R-EXL")		
Work	"Work" refers to the content of tasks using one or more tools. For example,		
	you would register the content of a work as "tasks done 10 times with a		
	cordless power tool, 3 times with the Check Pen S, and 1 time with an		
	approval stamp."		
Work sequence	Reservation for work executions is called a work sequence.		
	You can reserve executions for up to 8 works as shown below.		
	Work A Work B Work C		
	Currently Next Subsequent Running Work Scheduled Work Scheduled Work		
	The number of repetition times (1-99999 times) can be set for each work. Set		
	the number of repetition times according to the number of manufacturing		
	products.		


Tools available for POKAYOKE plus

Tool type	Description	
Tool	Compatible with various tools used in the production processes.	
	Check Pen S, Cordless Power Tool, Torque Wrench, Pliers Wrench, Approval	
	Stamp, Cable Tie Gun, Riveter, Grease Gun and more	
Safety protectors	Can be used with a hard hat.	
	Wearing status is OK · · · Wearing safety protectors correctly.	
	Wearing status is NG · · · Wearing safety protectors not correctly.	
	For use with a hard hat, NG wearing status includes:	
	The chin strap comes off. A hard hat is not worn.	


"Production Process Support Software for POKAYOKE tool, POKAYOKE plus" is a Windows- compatible application that can be used with POKAYOKE receivers capable of LAN connection for customers who want to ensure the traceability of "Tasks using tools" or "Wearing safety protectors" by workers at manufacturing plants.

 You can log and save task results for each work via the TW-800R-SCL or TW-8##R-EXL installed in multiple processes.


Work



- ●Start Date and Time of Task ●End Date and Time of Task
- •Judgment Result •Cause of FAIL, etc.
- 2. By using POKAYOKE plus, linked to TW-800R-SCL installed for multiple processes, you can set work execution instructions, counting the number of tasks upwards, etc. Since you can register installed TW-800R-SCL at up to 8 stations for one work, the system can prevent mistakes (pokayoke) for tasks that use up to 8 tools.




3. By linking the Pokayoke receiver without counter feature TW-8##R-EXL, the count can be displayed at up to 16 stations by locating a Windows computer with "POKAYOKE plus Viewer" (Windows-compatible application with the counter feature excerpted from POKAYOKE plus) at your task site.



^{*}To use POKAYOKE plus Viewer, you need to purchase one license for each POKAYOKE plus Viewer.


4. By linking works with external devices, you can control other facilities through the I/O port of the I/O unit or call the person in charge in the distance using the two-way Silwatch, upon completion of the work or occurrence of FAIL.



4 Notifies the occurrence of FAIL to people at some distance using the *two-way Silwatch system.

^{*}Two-way Silwatch system can only be used in Japan.

5. Hard-hat-on Sensor ENS-HH01 (*1) is an IoT tool for customers who "Encourage employees to wear hard hats correctly to ensure safety", and supports customers on how to wear hard hats.



(*1) Hard-hat-on Sensor ENS-HH01 is an IoT tool for customers who "Encourage employees to wear hard hats correctly to ensure safety", and supports customers on how to wear hard hats.

It senses the hard hat wearing status (whether the chin strap is securely fastened or not) in real time, and communicates with the receiver wirelessly.

For details, refer to "Hard-hat-on Sensor ENS-HH01 Instruction manual".

1-2. System Requirements

The following system requirements are necessary to use POKAYOKE plus.

Supported OS	Windows® 10 32-bit / 64-bit	
Supported OS	Windows® 11 64-bit (*)	
CPU	Intel® Core™ 2.3GHz or above (*)	
Memory	4GB or above (*)	
Screen Resolution	1366×768(FWXGA) or above	
Storage free space	1GB (Excluding data / log)	
Network Adapter	100Mbps or above(one or more network adapters available)	
USB Port	1 port(For connection to the two- way Silwatch transmitter/receiver only.)	
.NET Framework	4.6 or later installed	

^{*} For Windows 11, the minimum system requirements of Windows 11 apply additionally.

1-3. Supported Devices

POKAYOKE plus can be used in combination with the devices with the following model.

Pokayoke Transmitter

[Tools] Pokayoke Transmitter

TW-800T/TW-810T/TW-820T/TW-850T/HRF-2402/HCP-2402T-MC/Check Pen S

The transmitter can be mounted on the torque wrench with a limit switch, the check pen, the pliers wrench, the cordless power tool, etc., and a completion signal such as tightening can be wirelessly transmitted to the receiver.





TW-800T

ENS-HH01

[Safety protectors] Hard-hat-on Sensor ENS-HH01

The device senses the hard hat wearing status in real time and wirelessly transmits the information to the receiver. The device can be attached to any hard hat available in the market.

For the transmitter, this instruction manual describes only the contents required for using it with the receiver. For details, refer to each transmitter manual.

Pokayoke Receiver

Simple Pokayoke Counter TW-800R-SCL

TW-800R-SCL is a receiver with a built-in wireless feature and a simple counter feature.

It communicates with the transmitter one to one.

For details, refer to "TW-800R-SCL Instruction manual".



LAN Connection Type Pokayoke Receiver TW-8##R-EXL


A TW-800 series LAN connection type receiver.

The receiver is capable of communicating with multiple transmitters.

For details, refer to "TW-800R-EXL Instruction manual" or

"TW-820R-EXL Instruction manual".

↑ TW-820R-EXL can only be used in Japan.




I/O Unit

WCP-232-EXL

LAN connection type I/O unit with 32 contacts (16 input contacts and 16 output contacts).

To use the device by connecting it to POKAYOKE plus, it runs according to the specifications below.

- Input: 1-8, 17-24 / Output: 9-16, 25-32 (input signal must be 500ms or more)
- A-Contact



WCP-232-EXL

Silwatch

⚠ These products can only be used in Japan.

[Silwatch] Two-way Silwatch Wristwatch type transmitter/receiver SWSR-2130

It receives a signal from the transmitter/receiver and transmits the information in the form of up to 10 Chinese characters in text and sound, light or vibrations to the receivers.

[Silwatch] Two-way Silwatch transmitter/receiver SWSR-P125


For details, refer to each manual.



2. Mouting Method

2-1. Equipment configuration

- Connect the LAN connector of the receiver to the switching hub or the PC's LAN connector with the cable. Please use the cable of the category 5 or higher standard.
- The receiver or I/O unit is not equipped with AutoMDI/MDI-X function to determine the LAN port.
 To connect the receiver to the PC's LAN port directly, use a cross-wired LAN cable. "
- To connect the PC to the two-way Silwatch transmitter/receiver, install an FTDI driver separately. Download the latest FTDI driver from FTDI's website.



2-2. Network Settings

POKAYOKE plus communicates with the receiver via LAN. To connect the receiver to LAN, configure network settings according to your network environment. For details of the settings, such as IP address, contact the network administrator. For the setting method, refer to "TW-800R-SCL Instruction manual" or "LAN Basic Settings" attached to TW-8##R-EXL.

2-3. Selection of Operating Mode

To use TW-800R-SCL, the operating mode needs to be set.

With the TW-800R-SCL, you can select one of two operating modes: "stamd-alone mode" or "application interlock mode." When using TW-800R-SCL with POKAYOKE plus, select "application interlock mode". For the setting method of the operation mode, refer to "TW-800R-SCL Instruction manual".

2-4. Setting the receiver data type

There are two types of output data for the receiver "short data" and "long data". When using in combination with the transmitter ENS-HH01, set to "Long Data". For details, refer to transmitter manual.


3. POKAYOKE plus

3-1. Installation


Install the application according to the following procedure.

1) Insert the CD-ROM into the PC.


From "Explorer", double click the "setup" file in the Installer folder in the CD-ROM drive.



② Click "Next (N) >" and follow the instructions on the screen.



③ When the "Installation is completed" screen is displayed, installation of "setup" file is completed.




- 4 Install Visual C++ redistributable runtime packages.
- ♦When using a 64bit OS.

Directly double click "vcredist x64"(a) file in the Installer folder of CD-ROM drive.

♦When using a 32bit OS.

Directly double click "vcredist x86"(b) file in the Installer folder of CD-ROM drive.



Installation is now completed.

Software Updates

Customers who purchased POKAYOKE plus / POKAYOKE plus Viewer can download the latest version of the application free of charge from the download page of the website.

Previous Version: V1.0X, V2.00, V3.00

Latest Version : V3.01

Follow the steps below to update.

- ① The downloaded file is ZIP compressed, so decompress it.
- ② Open the Update folder and double-click the "setup" file directly.
- ③ Click "Next (N) >" and follow the instructions on the screen.
- 4 When the "Installation is completed" screen is displayed, installation is completed.


[Cautions for use]

The database of POKAYOKE plus is expanded with the addition of functions in V3.01.

Therefore, if you upgrade from V1.0X or V2.00 to V3.01, you cannot revert to the original version.


The registration information of V1.0X or V2.00 can be used as it is in V3.01.

3-2. Screen Configuration




Item name	Description	
①HERUTU logo	Click this to display the "Work execution status" screen.	
②Menu	Select a menu item.	
③Notifications	Messages, such as error information, are displayed. When a notification occurs, the number of messages is displayed on the top left of the bell icon. Click this to check the details of the notifications. For details of the messages, refer to "6. Troubleshooting".	
@Zooming	To zoom in or out the screen.	
⑤Display/hide menu	To hide or display the menu.	
6Main screen	This is a main screen.	

3-3. Menu Configuration



3-4. Flow of setting and operating POKAYOKE plus

Items marked with a circle(O) in "Tools" are required for the tools with POKAYOKE. Items marked with a circle(O) in "Safety protectors" are required for the safety protectors with POKAYOKE.



3-5. POKAYOKE plus Start up

When the installation is completed, start up POKAYOKE plus from the icon on the desktop or from Program.




3-6. Default Settings

Click [Default] in the menu to display the default settings screen.

♦Tools

Click the "Tools" tab.



To save the settings in this screen, click the Setting button on the bottom right of the screen. When moving to another screen without clicking the Setting button, the entries made on the Default settings screen will be lost.


Item	Description	Setting value
Buzzer sounds for PASS	When the number of tasks completed reaches	ON (default)
judgment	judgment a specified count, a "PASS" is assigned. Set	
	whether or not to sound the buzzer from the	
	PC equipped with the POKAYOKE plus.	
Buzzer type for PASS	Set the buzzer sound for notification of PASS	Buzzer1 (default)
judgment	result. Select a buzzer sound from five types.	Buzzer2
	You can hear the buzzer sounds after clicking	Buzzer3

		Buzzer4
	displayed on the right.	Buzzer5
Buzzer sounds for FAIL	When tasks are not executed according to the	ON (default)
judgment	execution instructions set in work registration,	OFF
	or when there are remaining counts at the	
	input of the judgment signal, the work is	
	judged as FAIL.	
	Set whether or not to sound the buzzer from	
	the PC equipped with thePOKAYOKE plus.	
Buzzer type for FAIL	Set the buzzer sound for notification of FAIL	Buzzer1
judgment	result. Select a buzzer sound from five types.	Buzzer2 (default)
	You can hear the buzzer sounds after clicking	Buzzer3
	■ 3)	Buzzer4
	displayed on the right.	Buzzer5
ToolReset timer	Time from when the tool is judged as PASS	1 sec. (default) – 30
(1-30 sec)	until when the next tool is started. When over-	sec.
	count is not permitted, by execution of task	(Set at one second
	while the reset timer is running, the next tool(s)	interval)
	and work are judged as FAIL for overcounting.	
WorkReset timer	Time from when the work is judged as PASS	1 sec. (default) – 30
(1-30 sec)	until when the next work is started.	sec.
		(Set at one second
		interval)
Judgment timing of work	Choose from one of the following:	•When all tools
(TW-8##R-EXL)	•When all tools complete the number of tasks	complete the number
	specified by the count, the system judges the	of tasks specified by
	work.	the count, the system
	(When all tool counts reached the specified	judges the work.
	value, the work is judged as PASS. The	(default)
	system move on to the next work after timeout	
	of the reset timer.)	 Judges a work
	•Judges a work when the judge signal is input.	when the judge
	(Judges a work when satisfying the conditions	signal is input.
	to "Judge work "in the external device interface	
	settings. When the predetermined number of	
	counts for all tools is reached, start the next	
	work. If "Judge work" is not registered in	
	External device interface settings, next work	

	cannot be started.)	
Judgment timing of work	Choose from one of the following:	·When all tools
(TW-800R-SCL)	•When all tools complete the number of tasks	complete the number
	specified by the count, the system judges the	of tasks specified by
	work.	the count, the system
	(When all tool counts reached the specified	judges the work.
	value, the work is judged as PASS. The	(default)
	system move on to the next work after timeout	
	of the reset timer.)	 Judges a work
	•Judges a work when the judge signal is	when the judge
	input. (Judges a work when the signal is	signal is input.
	input into the judge input terminal box of TW-	
	800R-SCL or when the conditions to "Judge	
	works" in the external device interface settings	
	are satisfied. When the predetermined	
	number of counts for all tools is reached, start	
	the next work.)	
Processing method for reset	During occurrence of FAIL, select Terminate	Continue (default)
input	the work by reset input from TW-800R-SCL,	Exit
	I/O unit or POKAYOKE plus Viewer, or select	
	Continue the work.	
	•Continue : Reset FAIL and continue the task.	
	•Exit : Finish the work in execution.	
Counting method	Set a counting method on the work execution	Count up
	screen of the application. This setting is also	Count down (default)
	reflected to TW-800R-SCL and POKAYOKE	
	plus Viewer.	

♦Safety protectors

Click the "Safety protectors" tab.



To save the settings in this screen, click the Setting button on the bottom right of the screen. When moving to another screen without clicking the Setting button, the entries made on the Default settings screen will be lost.

Item	Description	Setting value
Buzzer sounds when the	Set whether or not to sound the buzzer when	ON (default)
safety protector wearing	safety protectors are not worn correctly from	OFF
status is NG	the PC with POKAYOKE plus installed.	
Buzzer type when the safety	Set the buzzer sound for when safety	Buzzer1 (default)
protector wearing status is	protectors are not worn correctly. Select a	Buzzer2
NG	buzzer sound from five types. You can hear	Buzzer3
		Buzzer4
	the buzzer sounds after clicking	Buzzer5
	displayed on the right.	
Day of the week to monitor	Put a checkmark on the days to which the	Sun, Mon, Tue, Wed,
safety protectors	working hour pattern to be set in Create a	Thu, Fri, Sat (default:
	safety protector group applies. Set the day for	Checked every day of
	the start time of the working hours.	the week)
	Even when the day changes to the next during	
	working hours, the monitoring continues.	
	Example) When working from 17:00 on	
	Monday to 2:00 on Tuesday, put a checkmark	
	on Monday.	
Time until when the safety	Time from when the wearing status actually	0 min. (default) – 30
protector wearing status is	becomes NG (e.g. the hard hat chinstrap	min.
judged as NG	comes off) until when "Alert generated" is	(Set at one minute

(0-30 min)	notified. If you want to know the NG state	interval)
	immediately, set the time to 0 minute. To	
	accept the wearing NG state for a certain	
	period of time, such as a bathroom break, set	
	any desired time.	
Output of safety protector	The wearing status sent from the safety	ON (default)
history data (CSV format)	protectors is automatically saved in CSV	OFF
	format in the order received(*2). Output when	
	the wearing status changes.	
	[Output destination folder]	
	C:/HERUTU¥POKAYOKE plus/safety_log	
	[File name]	
	safety_log_yyyyMMdd.csv (y: year, M: month, d: day)	
	When the time set in "Update time for safety protector history file	
	(hours : minutes)" below has reached, a new file is created	
	automatically once a day.	
	*Do not open the file while executing POKAYOK	E plus. When opening
	the file while executing POKAYOKE plus, the receiver fails to write from	
	POKAYOKE plus. Exit POKAYOKE plus, and then open the file.	
Update time for safety	Time to create a new safety protector wearing	00:00(default)
protector history file	history file.	
(hours : minutes)		


(*2) The output contents are as follows.

Item	Description	Example
Transmitter ID	Transmitter ID of safety protector.	010800002F
Tool name	Tool name registered in register POKAYOKE Tools.	Worker A
Tool model	Tool model registered in register	ENS-HH01
	POKAYOKE Tools.	
Safety protector types	safety protector type registered in register	Helmet
	POKAYOKE Tools.	
Wearing status	OK···Wearing safety protectors correctly.	ОК
	NG···Wearing safety protectors not correctly.	
Date and time	Date and time when the wearing status changed.	2019/4/10 12:00:00
Safety protector group	Group name registered in register group.	Pressing Process G
name		

^{*}To view a wearing history and also to avoid garbling, it is recommended to open the file by following the procedure in "◆How to open History (in CSV file) ".

♦Common

Click the "Common" tab.



To save the settings in this screen, click the Setting button on the bottom right of the screen. When moving to another screen without clicking the Setting button, the entries made on the Default settings screen will be lost.

Item	Description	Setting value	
Language	Select a language to be displayed in Japanese		
	POKAYOKE plus.	English (default)	
Output of all data transmitted	All task data is automatically saved in the CSV	ON	
from the tool (CSV format)	format in order of receiving the data from the	OFF(default)	
	tools(*3).		
	[Output destination folder]		
	C:¥HERUTU¥POKAYOKE plus		
	[File name]]		
	raw_yyyyMMdd.csv (y: year, M: month, d: day)		
	A new csv file is created each day.		
	When the date changes while executing POKAYOKE plus, a new file		
	is automatically created.		
	*Do not open the file while executing POKAYOKE plus. When		
	opening the file while executing POKAYOKE plu	ıs, the receiver fails to	

	write from POKAYOKE plus. Exit POKAYOKE p	lus, and then open the
Character code(UTF-8)	Byte order mark	Available (default)
	CSV file may be garbled by changing this	None
	setting. Do not change this setting unless	
	special reasons apply.	
Network adapters	Select a network adapter to communicate with	Your IP address is
	POKAYOKE plus Viewer.	displayed in the
	For details, contact the network administrator.	selection list.
MQTT output	By being linked to the IoT environment that	ON
	supports MQTT, when an error occurs, it can	OFF(default)
	be informed to the mobile terminal of the	
	administrator, etc. by email or SMS.	
	When an error occurs while working with a tool	
	or while wearing safety protectors, the error	
	information is transmitted via the IoT standard	
	protocol MQTT.	
MQTT communication setting	gs POKAYOKE plus runs as a publisher.	
*For specifications, refer to "3-	-17. Transmission of error information to smartphones	or other devices in
real time.".		
Broker URL	Enter the broker URL.	empty(default)
Port No.	Enter the MQTT connection port number.	8883(default)
	Possible values: 1883, 8883 and 49152 -	
	65535	
Client ID	Enter a client ID to identify the client. (Only	GUID(default)
	alphanumeric characters can be used.)	
TLS 1.2	Turn ON to encrypt communication.	ON(default)
		OFF
QoS	QoS setting that guarantees the arrival	0 (default)
	between the publisher and the broker. Select	1
	from "QoS 0 (At least once)", "QoS 1 (At least	2
	once)", or "QoS 2 (Exactly once)".	
User Name	ID for authentication.	empty(default)
	Enter according to the broker settings.	
Password	Password for authentication.	empty(default)
		I
	Enter according to the broker settings.	
Topic name for FAIL judgme		Tools (default)

FAIL		
Topic name for generation of	Enter the topic name when publishing with	SafetyProtectors
a safety protector alert or for	MQTT.	(default)
resetting the alert		
Call Silwatch	Set this to ON to call two-way Silwatch	ON
	wristwatch type transmitter/receiver when the	OFF(default)
	conditions for setting "Call Silwatch" in	
	external device interface settings are met.	
	When this is set to OFF, the call is not	
	executed even when the conditions for setting	
	"Call Silwatch" are met.	
Transmitter /receiver	Select a COM port that is connected to the	COM port existing in
connection port	two-way Silwatch transmitter/receiver and that	PC is displayed in
	is recognized by the PC.	the selection.
Transmission interval	Select a time interval (seconds) of the call	15
	from the two-way Silwatch transmitter/receiver.	30(default)
		45

(*3) The output contents are as follows.

Item	Description	Example
Received date	Date receiving the transmitter ID from the receiver.	2019/04/10
Received time	Time receiving the transmitter ID from the receiver.	12:00:00
Transmitter ID	Tool or safety protector transmitter ID	010100002F
Transmitter	Transmission type, battery information, safety	[short data] 2byte
information(*4)	protector wearing status, error informationetc	01
		[long data] 26byte
		0101000000000000000000
		00000

(*4) There are two types of output data for the receiver "short data" and "long data". The data size of the transmitter information varies depending on the data type setting.

When using in combination with the transmitter ENS-HH01, set to "Long Data". When used in combination with the transmitter TW-800T, both "short data" and "long data" will work.

【Transmitter information detail】


	Transmission	Safety	Error	
	type, Battery	protector	information	System area
Ex)	information	wearing status	IIIOIIIIalioii	
	01	01	00	0000000000000000000

Data name	Description	Number of bytes
Transmission type, Battery information [short data]/[long data]	Normal transmission "01" Test transmission(battery capacity is normal) "02" Test transmission(battery capacity is low) "12"	2
Safety protector wearing status [long data]	Wearing status is NG "00" Wearing status is OK "01"	2
Error information [long data]	No error "00" Error No. in sequential order from "01"	2
System area [long data]	Contains system specific data. When using the output data in your environment, re ad and discard the data in the system area.	20

Output data example


[short data] "2019/04/10","12:00:00","010100002F","01"

3-7. Recever Registration



Click "Registration" on the menu, and "Receiver registration" (1) is displayed. Click "Receiver registration" to display the receiver registration screen.

Click "Receiver registration" button (②), and the information entry screen to enter a new receiver is displayed.




 Enter each information and click "Save" to save the information. If you click "Close" before clicking "Save", the entered information will be lost.

If you put a check in the box next to "Display the previously entered information after saving.", the entered data remains on the screen after clicking "Save". If you remove the check, after clicking "Save", the entered data will be cleared from the screen.

Item	Description	Input example:
Receiver name	Enter the receiver name.	ASSY line A
	(Maximum 16 characters)	
Receiver type	Select the receiver type.	TW-8##R-EXL(default)
	TW-8##R-EXL / TW-800R-SCL	
IP address	Enter the IP address of the receiver.	192.168.100.105
Port No.	Enter the port number of the receiver.	50001(default)
	The possible setting range is 10001 and 49152 –	
	65535.	
	Default value is 50001.	

Edit registration information / Copy the registered information to make a registration



When the receiver is registered, the application starts connecting to the receiver automatically. The connected receiver is displayed in white background (③) and the unconnected receiver is displayed in pink background (④). Soon after registration of the receiver, the connected receiver may remain displayed in pink background. Display the receiver registration screen again after moving to another screen, and the latest status is displayed. When the connection fails, the user is notified by notifications (⑤).

The possible cause of the connection failure is as below:

- •The receiver is not turned on or the power cable is not connected.
- •The LAN cable is disconnected.
- •The receiver's IP address/Port No. is not correctly set.

Button	Description		
Edit	The receiver name can be edited.		
Luit	The receiver type, IP address or Port No. cannot be	edited.	
Сору	The registered receiver information can be copied and then newly registered. When the receiver with the same IP address and Port No. is already registered, a		
	message asking if you want to overwrite with newly entered data is displayed.		
	Confirm	×	
	Receiver with the same IP address and port No. exists.Do you want to overwrite it?	already	
	Overwrite	Cancel	


Narrowing down of the receivers (registered information)

Enter the filtering conditions (⑥) and click and displayed.

You can enter any string in receiver name, IP address and port number. Receivers that match the entered string exactly or partially will be extracted. You can select either TW-8##R-EXL or TW-800R-SCL as the receiver type, and the matching receiver will be extracted.


When several conditions are entered, the receivers that match all conditions are extracted.

Deletion of the receivers (registered information)




Put a check in the box for the receiver you want to delete and click will be deleted.

3-8. I/O unit Registration




Click "Register" on the menu, and "I/O unit registration" (1) is displayed. Click "I/O unit registration" to display the I/O unit registration screen.

Click "I/O unit registration" button (②), and the information entry screen to enter a new I/O unit is displayed. 16 of I/O units can be registered.



Item	Description	Input example:
I/O unit name	Enter the I/O unit name.	ASSY line A
	(Maximum 16 characters)	
I/O unit type	Select the I/O unit type.	WCP-232-EXL(default)
	Default value is WCP-232-EXL.	
IP address	Enter the IP address of the I/O unit.	192.168.100.105
Port No.	Enter the port number of the I/O unit.	50001(default)
	The possible setting range is 49152 – 65535.	
	Default value is 50001.	

Edit registration information / Copy the registered information to make a registration



When the I/O unit is registered, the application starts connecting to the I/O unit automatically.

The connected I/O unit is displayed in white background (③) and the unconnected I/O unit is displayed in pink background (④). Soon after registration of the I/O unit, the connected I/O unit may remain displayed in pink background. Display the I/O unit registration screen again after moving to another screen, and the latest status is displayed. When the connection fails, the user is notified by notifications (⑤).

When the connection fails, the following causes are possible.

- •The I/O unit and LAN conversion unit are not connected.
- •The I/O unit is not turned on or the power cable is not connected.
- •The LAN cable is disconnected.
- •The I/O unit's IP address/Port No. is not correctly set.

Button	Description	
Edit	The I/O unit name can be edited.	
Edit	The I/O unit type, IP address or Port No. cannot be edited.	
Сору	The registered I/O unit information can be copied and then newly registered.	
СОРУ	When the I/O unit with the same IP address and Port No. is already registered, a	
	message asking if you want to overwrite with newly entered data is displayed.	
	Confirm	
	I/O unit with the same IP address and port No. already	
	exists.Do you want to overwrite it?	
	Overwrite Cancel	


Narrowing down of the I/O units (registered information)

Enter the filtering conditions (6) and click and displayed.

You can enter any string in I/O unit name, IP address and port number. I/O units that match the entered string exactly or partially will be extracted.

When several conditions are entered, the I/O units that match all conditions are extracted.


Deletion of the I/O units(registered information)



Put a check in the box for the I/O unit you want to delete and click of the I/O unit you want to delete and click be deleted.


When the selected I/O unit is set to the external devices, the settings of the I/O unit are deleted from all works using the I/O unit. Accordingly, some of the external device interface settings may not be executed. The I/O units used in the work or work sequence in progress cannot be deleted.

3-9. Tool Registration



Click "Registration" button on the menu, and "Tool registration" (①) is displayed. Click "Tool registration" to display the tool registration screen.

Click "Tool registration" button (②), and the information entry screen to enter a new tool is displayed. Unlimited number of tools can be registered.



A preview of the tool image is displayed.

If there is no image to display, it will be "No Image". It is not displayed when the tool type is other than

"Tool".

When "Tool" is selected from the tool type, the tool image can be registered. The registered image is displayed on the background of the count display on the work execution screen.

Supported image format:


- Bitmap(*.bmp)
- JPEG(*.jpeg, *.jpg)
- •GIF(*.gif)
- •PNG(*.png)

When registering an image with a large file size, the registration process may take some time.

Enter each information and click "Save" to save the information. If you click "Close" before clicking "Save", the entered information will be lost.

If you put a check in the box next to "Display the previously entered information after saving.", the entered data remains on the screen after clicking "Save". If you remove the check, after clicking "Save", the entered data will be cleared from the screen.

The tool type can be selected from "tool" or "safety protector". If you select "Safety protectors", "Safety protector types" will be displayed.



Item	Description	Input example
Transmitter ID Enter the 10-digit serial number indicated on the		010100002F
	transmitter.	
	Press the test switch of the transmitter paired	
	with the receiver while the entry screen is	
	displayed, and the serial number is automatically	
	entered. Please note that long pressing the test	
	switch will reset the pairing.	
	Test switch	
Type of the paired	Select the type of the paired receiver.	TW-8##R-EXL
receiver	TW-8##R-EXL / TW-800R-SCL	
Tool name	Enter the tool name. (Maximum 16 characters)	PliersWrenchR01
Tool model	Enter the tool model. (Maximum 20 characters)	P200Y2
Tool type	Select the tool type.	Tools
	Tools / Safety protectors	
Safety protector types	Select the safety protector type. This item is	Hard hats
	displayed when "Safety protectors" is selected for	
	the tool type.	
Tool image	Register and delete the tool image.	none(default)
	It is displayed only when "Tool" is selected for the	
	tool type.	

^{*}If a tool with the same transmitter ID has already been registered, you cannot additionally register with that transmitter ID. Delete the existing tool and try again.

Export / import of tool (tool, safety protector) information

Capture the tool information*1 from the file in CSV format and save the registered tool information in CSV format. You can register or edit multiple transmitters at the same time. It can also be used to transfer data to POKAYOKE plus running on another PC.

*1 Tool images are not subject to export / import.

♦Export

Click the "Export" button (③) and save it in any folder. When the export is completed, the message "Tool export is completed." is displayed.

Character encoding : UTF-8(with Byte order mark)

Line feed code : CRLF

*Cautions for editing or saving the exported file

- •Use a text editor (eg Notepad) to edit.
- The header is inserted on the first line. Enter from the second line according to the order of the items in the header.
- •Enclose each item in double quotation marks (").
- •Insert a comma (,) between items. Continue to enter data without placing space before or after comma.
- •When registering multiple tools, enter a new line.
- •When saving the data, specify "UTF-8" as the character code.

Setting item


Item	Description	Example
Transmitter ID	Transmitter ID	0101000001
Tool name	Tool name(Maximum 16 characters)	Check Pen S
Tool model	Tool model(Maximum 20 characters)	CP-02S
Type of paired receiver	Enter 1 or 2.	1
(1:TW-8##R-EXL、2:TW-800R-SCL)	1···TW-8##R-EXL / 2···TW-800R-SCL	
Tool type	Enter 0 or 1.	0
(0:tool、1:safety protector)	0···Tool / 1···Safety protector	
Safety tool type	Enter 0 or 1.	0
(0:other、1:hard hat)	0····Tool / 1····Hard hat	

Example


"010100350A", "Check Pen S", "CP-02S", "1", "0", "0"


"0201000007","Worker A","ENS-HH01","1","1","1"

◆Click the "Import" button (4) and select the file to import. A message appears when the import is complete. You can see the tools that were successfully imported and the number of tools that were unsuccessfully imported. For the reason for the import failure, check the content of the file output in "C:/HERUTU/Pokayoke plus/error_log". It lists the number of rows that failed and the reason.



Edit registration information / Copy the registered information to make a registration






Narrowing down of the tools (registered information)

Enter the filtering conditions (⑤) and click , and the receivers satisfying the conditions are selected and displayed. You can enter any string in transmitter ID, tool name. Tools that match the entered string exactly or partially will be extracted. Select the tool model, the paired receiver type, tool type and the type of safety protectors from the displayed selection information. The tools matching the conditions are extracted. When several conditions are entered, the tools that match all conditions are extracted.

Deletion of the tools(registered information)




Put a check in the box for the tool you want to delete and click. The registered information will be deleted. The work and work sequence using the selected tool are also deleted.

The tools used in the work or work sequence in progress cannot be deleted.


3-10. Work Registration and Start

Work refers to the contents of tasks using one or more tools. For example, you would register the content of a work as "task done 10 times with a cordless power tool, 3 times with the Check Pen S, and 1 time with an approval stamp".



Click "Registration" on the menu, and "Work registration" (1) is displayed. Click "Work registration" to display the work registration screen.

Click "Work registration" button (2), and the screen for newly creating a work is displayed. Unlimited number of works can be registered.



Narrowing down of the tools (registered information)

Enter the tool filtering conditions (③) and click and displayed.

You can enter any string in transmitter ID, tool name. Tools that match the entered string exactly or partially will be extracted. Select the tool model, the paired receiver type and tool type from the displayed selection information. The tools matching the conditions are extracted. When several conditions are entered, the tools that match all conditions are extracted.

Work creation

1. Enter work information in "Create work" (⑤) on the right.

Item	Description	Input example
external device	Turn it ON to interface the work with the devices,	OFF
interface	such as I/O unit or Silwatch, according to the	
	settings. For detailed setting method, please refer	
	to "External device interface setting" described	
	later.	
	•ON	
	•OFF(default)	
Tool sequence	Click ON to control the tool use sequence. Place	ON
	them in order of use from top to bottom.	
	•ON(default)	
	·OFF	
Work No.	Enter a desired work No. (Maximum 8 characters)	LU201-A
Work name	Enter a desired work name.	Large unit AD ASSY
	(Maximum 20 characters)	


2. Drag the tool in "Selection of tools" (④) on the left and drop it in the gray area of "Create work" (⑤) on the right. You can drag and drop up to 8 tools.

You can drag the tools moved to the right side and move them up and down. When the tool sequence is "ON", arrange the tools in order of task from top to bottom.

To create works, follow the rules below.


- A work cannot contain both the tools paired with TW-800R-SCL and the tools paired with TW-8##R-EXL.
- When Tool sequence is "ON", the same tool can be registered repeatedly in the same work.

3. Set the contents of task with the tool.



Item	Description	Input example	
Spec. value	Enter the task count.	6	
(Specified Count Value)	Range of the values that can be entered: 1 – 999		
Over-count	Over-count refers to execution of tasks more than	Over-count is	not
	the specified count.	permitted	
	When over-count is permitted, executing the task		
	more than the specified count will not be judged as		
	FAIL.		
	When over-count is not permitted, executing the		
	task more than the specified count will be judged		
	as FAIL.		


Example) When the contents of a work are "Task done 10 times with a cordless power tool", "Task done 3 times with the Check Pen S", and "Task done 1 time with an approval stamp".



4. Click "Registration" button and work creation is completed.


External device interface settings

To interface the work with external devices (e.g. I/O unit, Silwatch), settings need to be executed for each work before start of the work. The external device interface settings consist of conditions, events and actions.




Item	Description	
Condition	The condition is a set of two events. An event selected by a user and the	
	event to remove the event are included. Conditions with exactly the same	
	events cannot be set for a work.	
Event	Event means "Became a particular state".	
	For example, "Work became PASS" and "Work became FAIL" represent one	
	event each. An event has one or more actions associated with it.	
Action	Actions are associated with an event, and indicate "What to do" when the	
	event is satisfied. For example, "Judge work" and "Call Silwatch" each	
	represent one action.	

Example) When a work becomes FAIL, call a staff in charge using Silwatch, and inform people in all work area by the rotating light. When the FAIL state is cleared, stop the rotating light.




To perform external device interface settings, set External device interface settings to ON at the time of work registration. From the "Settings" button, open the Settings dialog to perform the settings.



Click the "Set" button, the following external device interface setting dialog is displayed. Click the "Add condition" button to add a new condition.



Click the "Add condition" button, and the "Add condition" button disappears and the display enters the edit mode for the conditions as shown below. Set the event and the action you want to perform.



	Description	Input example
1	Set the event. The event to be paired with the other event is automatically	Work became
	set.	"PASS"(default)
	The events that can be set are as follows.	
	•Work became "PASS"	
	•Work became "FAIL"	
	•I/O port is turned ON *1	
	•I/O port is turned OFF *1	
2	Set the actions to be associated with the event. The actions that can be	Call Silwatch

_			
		set vary depending on the event type.	
		The actions that can be set are as follows.	
		•Do nothing *3	
		·Call Silwatch	
		•Set I/O port to ON *1	
		•Set I/O port to OFF *1	
		•Judge work *2	
		Reset work *2	
(3	A button that adds a new action below the position where the button exists	-
		or deletes an action that exists at the position of the button.	
		Click the "+" button to add a new action below the button position.	
		Click the "-" button to remove the action at the button position.	
		If it cannot be used, it will be automatically disabled.	
(4	This button saves or discards the edited condition. Click Save to save the	-
		condition and exit edit mode. Click Cancel to cancel the edit mode in	
		which all the edited contents are discarded.	
		If it cannot be used, it will be automatically disabled.	

^{*1} Selectable only when one or more I / O units are registered.

The selectable events and the occurrence timing of the events are as described below.

Event	Timing of the event occurring
Work became "PASS"	The work is completed properly and becomes PASS.
Work became "FAIL"	The work becomes FAIL. After the work became PASS, it
Work became FAIL	becomes FAIL due to overcounting or other reasons.
L/O mont in trump of ON	A specific I/O port of a specific I/O unit changes from OFF
I/O port is turned ON	to ON.
I/O port is turned OFF	A specific I/O port of a specific I/O unit changes from ON to
I/O port is turned OFF	OFF.

^{*2} Selectable only when the event is "I/O port is turned on" or "I/O port is turned off".

^{*3} It can be selected only in the event paired with the selected event.

When setting an event, items for which additional settings are needed are as below.

Event	Additional setting items
Work became "PASS"	None
Work became "FAIL"	None
I/O port is turned ON	The target I/O unit (mandatory and selective)
I/O port is turned ON	The I/O port of the target I/O unit (mandatory and selective)
I/O port is turned OFF	The target I/O unit (mandatory and selective)
I/O port is turned OFF	The I/O port of the target I/O unit (mandatory and selective)

The selectable event, the event to be paired with the selected event and the occurrence timing are as below.

Event	Event to be paired	Timing of the event to be paired occurring
	Work is reset from "PASS"	•PASS for the work is reset and the next work is
		ready to be started.
Work became "PASS"		The work becomes FAIL immediately after
		becoming PASS.
		•The work is finished.
Work became "FAIL"	Work is reset from "FAIL"	The work continue to FAIL. or FAIL is reset as
Work became FAIL		the work is finished.
I/O port is turned ON	I/O port is turned OFF	A specific I/O port of a specific I/O unit changes
70 port is turned ON		from ON to OFF.
I/O port is turned OFF	I/O port is turned ON	A specific I/O port of a specific I/O unit changes
I/O port is turned OFF		from OFF to ON.

When setting actions, the items to be additionally set are as below.

Action Additional setting items	
	MID(Message ID, Required, Text input) *1
Call Silwatch	Message (Text input, Maximum of 20 characters (single or
	double byte)) *2
Sat I/O part to ON	The target I/O unit (mandatory and selective)
Set I/O port to ON	The I/O port of the target I/O unit (mandatory and selective)
Set I/O port to OEE	The target I/O unit (mandatory and selective)
Set I/O port to OFF	The I/O port of the target I/O unit (mandatory and selective)
Judge work	None
Reset work	None
Do nothing	None

^{*1)} Enter the registered MID to two-way Silwatch wristwatch type transmitter/receiver to be called.


To check or change the settings of two-way Silwatch wristwatch type transmitter/receiver, use the two-

way Silwatch Settings application (Optional) or contact our Sales Department.


*2) The message can be displayed on two-way Silwatch wristwatch type transmitter/receiver at a time is up to 20 single- byte characters or 10 double- byte characters. If this is exceeded, the message will be displayed only in the visible part from the beginning.

Example) When the work FAILs, call a person in charge using Silwatch and notify the whole work area with a rotating light at the same time. When FAIL is reset, stop the rotating light.


(Assume rotating light is connected to I/O port 9)



When editing the condition is completed, click the "Save" button, and the edited condition is confirmed and Condition edit mode is finished



	Description
1	The total number of actions set for the work.
	If 10 or more actions are set in each work, new conditions or actions cannot be added.
2	This button discards all settings made after the external device interface settings screen is opened
	and ends the settings. Click to display the following confirmation message, and click the "OK"
	button to discard the settings and close the dialog.




When the external device interface setting is completed, close the dialog and register the work.

At this time, make sure that the external device interface is turned on before registering.

If it is OFF, it will not work even if external device interface is set.


After registration of the work, start the work linked with the external devices to interface it with the external devices according to the external device interface settings.




For specifications of the device controlled by external device interface, refer to "3-18. Specifications for external device interface".

Start work / Copy the registered information to make a registration

Register work





Up to 16 works and work sequences in total can be started at the same time.

Once you click the Start button, you cannot click it until the work is completed.



When starting a work, the work is registered as a work sequence.

When starting a work, the work is registered as a work sequence.

When the tool contained in the work you want to start is used in the work or work sequence in progress, you cannot start the work.

Example) When using the same tool in "Large unit AD ASSY" and "Mid unit AK ASSY".

When clicking the Start button of "Large unit AD ASSY", the Start button of "Mid unit AK ASSY" is automatically disabled.



Сору

The registered work information can be copied and then newly registered.

Narrowing down of the works (registered information)

Enter the filtering conditions (6) and click and displayed.

You can enter any string in work No., work name, tool name, transmitter ID. Works that match the entered string exactly or partially will be extracted. Select the tool sequence from the displayed selection information. The works matching the conditions are extracted. When several conditions are entered, the works that match all conditions are extracted.


Deletion of the works (registered information)



Put a check in the box for the work you want to delete and click . The registered information will be deleted.


The work in progress cannot be deleted. The work sequence containing the work you want to delete will also be deleted.

3-11. Work Sequence Registration and Start



Click "Registration" on the menu, and "Work sequence registration" (1) is displayed. Click "Work sequence registration" to display the work sequence registration screen.

Click "Work sequence registration" button (②), and the screen for newly creating a work sequence is displayed. Unlimited number of Work sequences can be registered.



Narrowing down of the works (registered information)

Enter the work filtering conditions (③) and click , and the works satisfying the conditions are selected and displayed.

You can enter any string in work No., work name. Works that match the entered string exactly or partially will be extracted. When several conditions are entered, the works that match all conditions are extracted.

Work sequence creation

1. Enter a work sequence name.


Item	Description	Input example
Work sequence name	Enter a desired work sequence name.	Display C
	(Maximum 20 characters)	

2. Drag the work in "Selection of works" (4) on the left and drop it in the gray area of "Create work sequence" (5) on the right. You can drag and drop up to 8 tools.

You can drag the works moved to the right side and move them up and down. Arrange the tools in order of execute from top to bottom.


The work using TW-800R-SCL and the work using TW-8##R-EXL cannot be contained in the same work sequence.

3. Set the number of work execution count. (The task instructions are repeated as much as the execution count.)



Item	Description	Input example
Count	Enter the execution count.	100
	Range of the values that can be entered: 1 -	
	99999	


Example) When executing tasks in order from "100 units of large unit AD assembly" -> "10 units of midrange unit AK assembly" -> "57 units of large unit RT assembly".



4. Click "Registration" button and work sequence creation is completed.


Start work sequence / Copy the registered information to make a registration

Register Work Sequence



Button	Description
Start	Start a work sequence now. Up to 16 works and work sequences in total can be
Start	started at the same time.
	A work sequence and the safety protector group being monitored can be linked.
	The tool work status and the safety protector wearing status are displayed on the
	same screen. Select a desired safety protector group.(Safety protector group that
	are already associated with another work sequence will not be displayed.) For
	details on registration of safety protector group, refer to "3-12. Registration of

safety protector group and Start of monitoring.".



Once the Start button is clicked, it cannot be clicked until the work sequence is completed.



When the tool contained in the work sequence you want to start is used in the work or work sequence in progress, you cannot start the work.

Example) When using the same tool in "DisplayASSYLine J" and "DisplayASSYLine G".

When clicking the Start button of "DisplayASSYLine J", the Start button of "DisplayASSYLine G" is automatically disabled.



When the work contained in the work sequence you want to start is used in the work sequence in progress, you cannot start the work.

When the work is started, execution instructions are sent to TW-800R-SCL or POKAYOKE plus Viewer.

Сору

The registered work sequence information can be copied and then newly registered.

Narrowing down of the work sequences (registered information)

Enter the filtering conditions (⑥) and click , and the work sequences satisfying the conditions are selected and displayed.

You can enter any string in work sequence name., work name, transmitter ID, tool name. Work sequences that match the entered string exactly or partially will be extracted. When several conditions are entered, the works that match all conditions are extracted.

Deletion of the work sequences (registered information)



Put a check in the box for the work sequence you want to delete and click


■Work sequence

The registered information will be deleted.

The work sequence in progress cannot be deleted.


3-12. Registration of safety protector group and Start of monitoring

POKAYOKE plus can monitor up to 16 safety protector groups in parallel. Up to 16 safety protectors in each safety protector group. Unlimited number of safety protector group can be registered.



Click "Register" on the menu, and "Register Group" (①) is displayed. Click "Register Group" to display the safety protector group registration screen.

Click "Register Group" button (②), and the information entry screen to enter a new safety protector group is displayed. Unlimited number of Safety protector group can be registered.




Narrowing down of the tools (registered information)

Enter the tool filtering conditions (③) and click and displayed.

You can enter any string in transmitter ID, tool name. Tools that match the entered string exactly or partially will be extracted. Select the tool model, the paired receiver type and safety protector type from the displayed selection information. The tools matching the conditions are extracted. When several conditions are entered, the tools that match all conditions are extracted.

Create safety protector group

1. Enter the working time. Click the "Input" button to display the working time setting screen. Working time can be set for each safety protector group. The wearing status of the safety protectors is monitored during working hours.



Item	Description	Input example
Working time name	Enter a desired working time name. (Maximum 16	ASSY line A_day shift
	characters) Working time can be set for each safety	
	protector group.	
Start time	Enter the work start time.	08:00
End time	Enter the work end time.	10:00


^{*}Working hours exceeding 24 hours cannot be set.

Example) Settings for the following working hours

Start 8:00 ---- 10:00 ··· 10:10 ---- 12:00 ··· 12:40 ---- 15:00 ··· 15:10 ---- 17:00 End


Work Break Work Break Work Break Work

① Enter the working time name, start time (8:00) and the end time (10:00) after the break, and click plus "+".



Click the to add the working hour segment.

② Enter the start time (10:10) and the end time (12:00) after the break, and click plus "+".



3 Add all working hour segments and click the "Settings" button, and the settings for working hours are completed.




*Please note that the entered information will be discarded if you click the "x" in the upper right of the screen without pressing the "Setting" button.

A maximum of 20 working hour segments can be added.

♦In addition to the above methods, there is also a method of setting working times by using the import function.

Click the "Import" button to copy the working hours set in the registered safety protector group and register the working hours.






1. Enter the safety protector group No. and safety protector group name.

Item	Description	Input example
Safety protector group	Enter a desired safety protector group No	KA-01
No.	(Maximum 8 characters)	
Safety protector group	Enter a desired safety protector group name.	ASSY line A
names	(Maximum 20 characters)	

2. Drag the tool in "Selection of tools" (4) on the left and drop it in the gray area of "Create safety protector groups." (5) on the right. You can drag and drop up to 16 tools.


You can drag the tools moved to the right side and move them up and down.



3. Click "Register" button and safety protector group creation is completed.

Start monitoring / Copy the registered information to make a registration

Register Safety Protector Group




Button	Description
Monitoring	Click to switch monitoring ON / OFF. From the moment when switching from OFF to
OFF	ON during working hours, monitoring of the wearing status is started. When switching
ON	from OFF to ON during non- working hours, monitoring of the wearing status is started when the working hours start. The monitoring can be switched between ON/OFF anytime during working hours.
Edit	Edits the information of the registered safety protector groups. Changes the working hours, or adds/deletes tools. Edit is possible even during monitoring.
Сору	The registered safety protector group information can be copied and then newly registered.

Narrowing down safety protector groups (registration information)

Enter the safety protector group filtering conditions (⑥) and click and the safety protector groups satisfying the conditions are selected and displayed.

You can enter any string in safety protector group No., safety protector group name, tool name, transmitter ID. Safety protector groups that match the entered string exactly or partially will be extracted. Select the safety protector type from the displayed selection information. The safety protector type matching the conditions are extracted. When several conditions are entered, the safety protector groups that match all conditions are extracted.

<u>Deletion of the safety protector groups(registered information)</u>




Put a check in the box for the safety protector group you want to delete and click.

The registered information will be deleted.

When Monitoring is set to ON, the groups cannot be deleted. Change the Monitoring setting to OFF to delete the groups.


3-13. Work Execution Status Screen

The work and work sequence in progress are listed below. You can check the task execution status in real time.




Work sequence

Up to 8 works can be set and they are executed from top to bottom. When all works are completed, they automatically disappear from the Work execution status screen.



Select POKAYOKE plus Viewer



[For use of the receiver TW-8##R-EXL]

The display icon () is displayed below the work sequence name.


Click the icon and all of the connected POKAYOKE plus Viewer are displayed. Select your desired POKAYOKE plus Viewer.

To use this function, POKAYOKE plus and POKAYOKE plus Viewer must be connected beforehand. For details of POKAYOKE plus Viewer, refer to "POKAYOKE plus Viewer Instruction manual".

[For use of the receiver TW-800R-SCL]
 "TW-800R-SCL" is displayed.


Delete work sequence

Click on the top right of the Work execution status screen, and the following message is displayed.



Select the work sequence you want to delete and click "Delete" button.

Work sequence details screen




Click this area to display details of the work sequence (task contents of each work).




	Item	Description
1	Work name	Name of the work.
2	POKAYOKE plus Viewer	When POKAYOKE plus Viewer is specified, POKAYOKE plus
	or receiver name	Viewer name is displayed.
		When the receiver is TW-800R-SCL, the receiver name registered
		in receiver registration is displayed.
3	Tool name	Name of the tool.
4	Transmitter ID	ID of the transmitter.
5	Specified count	Task count of the tool.

3-14. Work Execution Screen



Click the work in progress, and the Work execution screen is displayed.



Indication of low battery


- Indicated when using the tool equipped with a transmitter with low battery detection and the battery is
 lower than a set value. Replace the battery with a good one and use a tool to disable the indication.
- (a) "Production number / set execution count" is displayed. The work order is repeated until the set number of times is reached.
- *The production number is the number of works whose judgment result is PASS. If "Finish the work in execution." is selected when FAIL occurs, it will not be counted.

When Tool sequence is ON, execute the tasks in increasing order from No. 1. When Tool sequence is OFF, No. is not displayed. Each time a task is executed, "Count value" counts up or down.

When the task is executed as much as the specified count, the task is judged as PASS and the frame of the tool and the count value (task count) turn blue.

Task is completed (PASS)

When all tasks are completed and they are judged as PASS, the frame of each tool, the count value and the outer frame of the whole work turn green.




FAIL occurs

When FAIL occurs, the frame of the tool during task execution, the count value and the outer frame of the whole work turn red.


[FAIL factors]

•Over-count: Occurs when the task is executed more than the specified count.



•Tool sequence error: Occurs when the tasks of the tools are executed in the wrong sequence.


*It occurs only when the tool sequence is ON.



Example) When executing the task with No.4 "Plier Wrench" without executing the task with No.3 "Torque Driver".

When the tasks are executed in the wrong sequence, the frames of the target tools and the count values turn red.


•Remaining count error: Occurs when a judgment input is provided when the task is not executed as much as the specified count.



Example) Judged and entered when the task with No.6 "Marking Pen 2" is completed (remaining task is left)

The tools used for the tasks that are not completed will be displayed in red.

When FAIL occurs, the following message is displayed and the task is temporarily interrupted. Enter a comment (optionally), select either "Continue" or "Exit" and click the Confirm button.



FAIL can be reset also by the reset input from TW-800R-SCL, I/O unit or POKAYOKE plus Viewer located at the task site. Set whether to exit the work by the reset input from TW-800R-SCL, I/O unit or POKAYOKE plus Viewer or continue the work according to "Processing method for reset input" in [Default settings]/[Tools].

Enlarge the tool in operation

When Tool sequence for the work is set to "ON", clicking will display only the tool in operation in enlarged form. Use this function to display the count values larger at the task site.

* When Tool sequence for the work is set to "OFF", this function cannot be used.




Click "Return" button to return to the original screen.

Click "Hide menu" to display the count in the full screen.

For multiple tools are used for one work, when the task with each tool is completed, the outer frame and the count value turn blue. After the reset timer has elapsed, the counter display changes to the count for the next tool.






Task is completed (PASS)

When PASS judgment is made, the outer frame and the count value turn green.








When the next work is set to be executed, after the reset timer has elapsed, the counter display changes to the count for the next work.

If there is no more work to be executed, after the reset timer has elapsed, the screen is switched to the Work execution status screen.

FAIL occurs

When FAIL occurs, the outer frame and the count value turn red.

Tool Replacement



Enter the transmitter IDs (10 digits) before and after the tool change and click the Change button. Use this function for the following.

- To replace the tool due to damage.
- To replace the transmitter (TW-800T, TW-850T) attached to the tool due to the damage of the transmitter.


Change

Cancel

3-15. Safety protectors wearing status screen

The safety protector group being monitored are listed. You can keep track of the wearing status of the safety protector in real time.

Click "Safety Protector Wearing Status" button on the menu. A maximum of 16 safety protector groups can be monitored in parallel.



[Explanation of terms]

Wearing status is OK · · · Wearing safety protectors correctly.


Wearing status is NG · · · Wearing safety protectors not correctly.

During non-working hours, the number of tools in the OK/NG wearing state is reset to 0.

The wearing status can be checked for each safety protector group. Each frame shows one safety protector group. The color of the icon changes depending on the wearing status.

Color	Status	
Black	Ready(off hours)	
Green	Wearing status is OK	
Red	Wearing status is NG	
Gray	All tools in the safety protector group are temporarily	
	stopped. (*5)	

Click a safety protector group to check the detailed wearing status of the safety protector group.



When the battery of the transmitter ENS-HH01 is getting low,

the icon indicating low battery level is displayed.


When the wearing status changes from OK to NG, it is indicated by a message and sound.

The alert is not cleared until the wearing status changes from NG to OK.



(*5) Click any tool to change the background color of the frame and the icon color to gray. This status is called a temporary stopping state.

Monitoring is not performed in a temporary stop state even during the working hours, and the wearing history is not recorded. An alert is not generated even after change of the wearing status from OK to NG. The temporary stop state is maintained even after restarting POKAYOKE plus. Click the tool again to reset the temporary stop. Until then, the temporary stop state continues.



The transmitter (ENS-HH01) mounted on the hard hat transmits the wearing status to the receiver at the

- ① A wireless signal is transmitted to indicate the wearing status each time the chin strap is fastened or removed.
- ② The signal is transmitted every 5 minutes from when hard hat wearing was detected, and the wearing status at that point is notified. When the chin strap is not securely fastened or not worn for 30 minutes, the transmitter stops transmitting a signal at regular time intervals.

◆Cautions for display of the wearing status of the safety protectors

When wearing safety protectors at the start of the working hours, an alert is generated. It may
take up to 5 minutes until the alert is cleared.

The reasons are as follows.

timing described below.


POKAYOKE plus ignores signals received during non-working times. Therefore, when workers are wearing safety protectors at the start of working hours, the wearing status becomes NG and an alert is generated. The transmitter transmits a signal every 5 minutes. When a signal is regularly transmitted, POKAYOKE plus updates the display to the actual wearing status.

 If workers enter an area where a wireless signal cannot reach the receiver while wearing safety protectors, the display of POKAYOKE plus is not updated even after change of the actual wearing status.


3-16. History

Two types of historical data are available. "Tool History" displays the task history for each tool. "Work Execution History" displays the task history for each work. The historical data of each type can be saved in the csv format.

•Tool History Click "History"/"Tools"/"Tool History" button on the menu.



•Work Execution History Click "History"/"Tools"/"Work Execution History" button on the menu.



Search history

Common to tool history and work execution history

Enter a desired information in "History search conditions" and click

while leaving the History search conditions field blank, and all of the stored data is displayed.

Search conditions are as below:

Item	Description Input example	
Working date	Enter the date the work was executed.	2018/8/1 ~ 2018/9/1
	Search the historical data whose Start Date and Time	
	of Task is within the range of the specified Date of Task.	
	The search range should be from 00:00:00 on the	
	search start date to 23:59:59 on the search end date.	
Work name	Enter a work name.	Large unit AD ASSY
Tool name	Enter a tool name.	Torque Wrench
Work No.	Enter a work No.	LU0101_AD
Transmitter ID	Enter the transmitter ID (10 digits).	000100002F
Judgement	Select judge result (PASS or FAIL).	FAIL
result		

View history

•The items of Tool History are listed below:

Item	Description Display example	
Transmitter ID	ID (10 digits) of the transmitter. 000100002F	
Tool name	Name of the tool.	Torque Wrench
Judgement result	Judgment result (PASS or FAIL).	FAIL
Cause of FAIL	FAIL factors (Over-count, tool sequence error and	Over-count
	count remaining error).	
Start Date and	Date and time when the task with the target tool 2018/9/1 08:30:00	
Time of Task	was started.	
End Date and Time	Date and time when the task with the target tool 2018/9/1 17:30:00	
of Task	was completed.	
Work No.	Number of the work.	LU0101_AD
Work name	Name of the work. Large unit AD ASSY	
Working sequence	Sequence of the target tools used in a work. 2	
of tool		
Spec. value	Specified count of the task.	6

•The items of Work Execution History are listed below:

	•	
Item	Description Display example	
Work No.	Number of the work. LU0101_AD	
Work name	Name of the work.	Large unit AD ASSY
Judgement result	Judgment result (PASS or FAIL).	FAIL
Cause of FAIL	FAIL factors (Over-count, tool sequence error and	Over-count
	count remaining error).	
Comment	A comment entered when FAIL occurred.	Continue work because
		there is no problem.
Execution	Set the number of work repetitions when the work	3
sequence of work	is started or a work sequence is created. Displays	
	the number of times out of the specified repetition	
	count that the task was executed.	
Start Date and	Date and time when the task was started.	2018/9/1 08:30:00
Time of Task		
End Date and Time	Date and time when the task was completed.	2018/9/1 17:30:00
of Task		

Historical data size

For example, when manufacturing 100 units using 4 tools, 400 tool historical data items and 100 work historical data items will be stored. In this case, the total data size of work history and tool history is approx. 150KB.

Maximum number of data items to be stored in history

Approx. 11,000,000 data items of tool history and work history can be stored in total.

Save history in the CSV format.

Click "Save search results in CSV format" button and the displayed history can be saved to any destination in the CSV format. It cannot be saved in the CSV format during work execution. Execute saving after all works are completed.

(Work execution refers to the situation where one or more work sequences are displayed on the Work execution status screen.)

A maximum number of output per file is 1 million. To save more than 1 million historical data, divide the data into data sets of 1 million and generate file output.

In this case, insert "_(n)" after the last digit (immediately before the extension) of the file name.

Example: tool 20180524 154122 1.csv, tool 20180524 154122 2.csv

The header indicating the item name of each information is not written to the file.

History (tool)

```
File name: tool_yyyyMMdd_HHmmss.csv Example: tool_20180901_083000.csv (Year: yyyy, Month: MM, Date: dd, Hour(s): HH, Minute(s): mm, Second(s): ss)
```

The items are displayed in order from left to right: "Transmitter ID", "Tool name", "Judgment result", "Cause of FAIL", "Start Date and Time of Task", "End Date and Time of Task", "Work No.", "Work name", "Working sequence of tool" and "Specified count".

History (work)


```
File name: work_yyyyMMdd_HHmmss.csv Example: work_20180901_083000.csv (Year: yyyy, Month: MM, Date: dd, Hour(s): HH, Minute(s): mm, Second(s): ss)
```

The items are displayed in order from left to right: "Work No.", "Work name", "Judgment result", "Cause of FAIL", "Comment", "Execution sequence of work", "Start Date and Time of Task", "End Date and Time of Task".


◆How to open history(CSV file)

When opening history (CSV file) in Excel, in order to avoid garbling, it is recommended to open the file following the steps below.


- 1. Start excel.
- 2. Select "Data" tab → "Get External Data".




3. Select "From Text".




- 4. Select the target CSV file and import it.
- 5. Select "Delimited -Characters such as commas or tabs separate each field." and click "Next".




6. Put a check in "Comma" in delimiters, and click "Next".



7. Select a row containing the transmitter ID (10 digit character string) from data preview, and then select "Text" for column data format and click "Finish".




8. Select the destination to put the data to and click "OK".



Delete history

Click "Deleted all history" button and a confirmation message is displayed.

To delete all history, click "Confirm" button.



All historical data of tools and works recorded in POKAYOKE plus as well as the history displayed on the screen will be deleted. Click the button on the "History (tool)" screen or the button on the "History (work)" screen, and all historical data of tools and works are deleted collectively.

Deleted history cannot be restored. Before deleting history, save data in the CSV format as necessary. History cannot be deleted during work execution. Execute deletion after all works are completed. Work execution refers to the situation where one or more work sequences are displayed on the Work execution status screen.

Maximum capacity of historical data

- When the historical data size approaches the maximum, the following message is displayed. In this
 situation, works or work sequences can be started. However, please note once the maximum
 capacity of historical data is reached, works or work sequences cannot be started.
 - "Historical data capacity is close to the maximum.
 - When the historical data capacity reaches the maximum, execution of works or work sequence cannot be started.
 - Delete history and clear the historical data area."
- When the maximum capacity of historical data is reached, works or work sequences cannot be started. When the following message is displayed upon clicking the Start button for the work or work sequence, delete historical data before starting the work or work sequence.
 - "The amount of history data has reached the maximum.
 - Cannot execute Work or work sequence, as no more history data cannot be written.
 - To start a work or work sequence, delete the history."

3-17. Transmission of error information to smartphones or other devices in real time(MQTT output)

When an error occurs while working with tools or wearing safety protectors, the error information is transmitted via IoT standard protocol MQTT in a real time. By linking POKAYOKE Plus with the IoT environment that supports MQTT, error information can be sent to the mobile terminal of the administrator, etc. by email or SMS at occurrence of an error.

POKAYOKE plus becomes MQTT publisher and sends messages to brokers.

*To use this function, enter the information required for communication in the default settings.

For details, refer to "3-6. Default Settings".

MQTT specification	Value
Version	3.11
Keep Alive	45 sec
Connection Timeout	30 sec

When encrypting communication (TLS1.2), save the certificate file in the following folder. When using a current mainstream public cloud service, due to the requirements of encryption in many cases, receive a certificate from the cloud service or obtain an access token.

Item	Setting value
CA certificate	ca.pem
Client certificate	client.pem
Key of client certificate	client_key.pem
Save destination folder	C:/HERUTU/POKAYOKE plus/safety_cert

When "MQTT output" of the default setting ("Common") is set to ON, when you start POKAYOKE plus, the connection to the broker is automatically started. You can check the connection status in "Connection status" of MQTT communication settings in [Default Settings] / [Common]. The client ID used in MQTT is the "Client ID" set in the default settings ("Common").

MQTT output specification

♦Tools		
Transmission	When FAIL occurs during work execution, or when FAIL is released.	
timing		
Topic	"Tools" (Set in default settings)	
Payload	FAIL information (JSON format)	
	{	
	"topic":"Tools",	
	"work_sequence_name":{Work sequence name},	
	"work_name":{Work name},	
	"failure_factor":{Cause of FAIL},	
	"status":{FAIL occurred("1") / Reset FAIL ("0")},	
	"datetime":{Date and time of occurrence(UTC)(yyyy-MM-dd HH:mm:ss)},	
	"utc_offset":{Difference between local time and UTC time}	
	}	

◆Safety protec	tors	
Transmission timing	The wearing status changes to NG or the wearing status changes to OK.	
Topic	"SafetyProtectors" (Set in default settings)	
Payload	Alert information (JSON format)	
	{	
	"topic":"SafetyProtectors",	
	"transmitter_id":{Transmitter ID},	
	"tool_name":{Tool name},	
	"tool_model":{Tool model},	
	"tool_category":{Safety protector types},	
	"status":{Wearing status is OK("1") / Wearing status is NG("0")},	
	"datetime":{Date and time of occurrence(UTC) (yyyy-MM-dd HH:mm:ss)},	
	"utc_offset":{Difference between local time and UTC time}	
	"safety_group_name":{Safety protector group name}	
	}	

3-18. Specifications for external device interface

The following explains about specifications for control of each device according to the external device interface settings for the works.

I/O Unit

- The timing of the event occurring, which is triggered by the I/O port status

The I/O port and POKAYOKE plus are connected via TCP and controlled by a software. Actions in the unit of milliseconds (ms) or faster are not guaranteed. In our ideal environment *1, it is confirmed that an event occurs within 500ms after the port changed the status. However, the same level of performance is not guaranteed in all environments.

- The default status of the I/O port and status of the I/O port after work

All contacts of the I/O port are Form A, and the default state of the contacts is OFF (0). When the work is finished, the status of the output I/O port controlled by the external device interface settings of the work is not maintained.

Control of the same I/O unit and output I/O port used for different works

For several works, when setting the output I/O port of the same I/O unit to ON (1) or OFF (0), the final output result is OR (logical sum) of the default state of OFF (0) and all actions. For example, when Work A and Work B become FAIL, set the I/O port10 of the I/O unit A to ON. When FAIL for the work is reset, set the I/O port10 of the I/O unit A to OFF.

- •If either Work A or Work B is in the FAIL state, the status of the I/O port10 of the I/O unit A is ON (1).
- •Otherwise it will be OFF (0).

When connection with the I/O unit is cut off during control of the output I/O port

When connection between the I/O unit and PC is cut off, the status at the time of being disconnected is maintained until they are reconnected. When reconnected, all output I/O ports will be OFF due to device initialization. After the initialization is completed, the control by the external device interface setting is restarted.

Silwatch

Timing of call

Call Silwatch are stored in memory in order of occurrence (Up to 100 sets of data is stored. When the memory becomes full, new arriving data is discarded.) and transmitted in sequence at the transmission intervals selected in the default settings. Thus, when the action of Call Silwatch is executed, it may take some time to be actually called.

When several actions of Call Silwatch are executed at the same time, the one call action takes longer than the transmission intervals selected in the default settings until the call is actually executed. This is a function to prevent communication interference and facilitate communication.

- Specification of call Silwatch

Call Silwatch from POKAYOKE plus are always transmitted to all Two-way Silwatch Wristwatch type transmitter/receiver.

To narrow down the calls to Two-way Silwatch Wristwatch type transmitter/receiver only, settings must be made for Two-way Silwatch Wristwatch type transmitter/receiver.

To check or change the settings of Two-way Silwatch Wristwatch type transmitter/receiver, use the two-way Silwatch Settings application (Optional) or contact our Sales Department.

- Guarantee of the call arrival to Two-way Silwatch Wristwatch type transmitter/receiver


Even if Call Silwatch is executed, whether the call reaches Two-way Silwatch Wristwatch type transmitter/receiver or not is depending on the environment and the arrival of the call is not always guaranteed.

*1) The environment satisfies the system requirements and is capable of dominating the bandwidth, and where other applications do not start up.

3-19. Error Code

When an error occurs while communicating with TW-800R-SCL, an error code is notified by TW-800R-SCL.

When an error code is received, please contact our sales department.



3-20. Product Information

The application information, including the version information, can be checked.



3-21. Exit POKAYOKE plus



Click "X" on the top right of the screen, and a message "Do you want to exit?" is displayed. Click "OK" and the application exits.

When executing a work or work sequence, a message "Work in execution exists. Do you want to save the interrupted data?" is displayed.

When "Yes" is clicked

The work or work sequence in progress is interrupted and the current state is saved. At next startup, the task can be started from the interrupted state.

When "No" is clicked

The work or work sequence in operation is all abandoned.

(This message uses Windows functions, the language of the "OK", "Yes", "No" and "Cancel" buttons depends on the language set in the OS.)

4. Actions When Receiver TW-800R-SCL Is Used

Before registration of the receiver to POKAYOKE plus

When the receiver is registered to POKAYOKE plus, the communication between the receiver and POKAYOKE plus is started.

The network monitor of TW-800R-SCL blinks until the communication is established. (7 segment LED is OFF.)



After registration of the receiver to POKAYOKE plus

When the receiver is registered to POKAYOKE plus, the standby state is displayed. The network monitor LED changes from blinking to lit. This status continues until execution instructions from POKAYOKE plus are received.




Start work or work sequence with POKAYOKE plus


Select either one of following work judgement timing in the Default settings of POKAYOKE plus. When the work is judged as PASS, after the reset time is reached, the next work will be automatically started.

- (a) When all tools complete the number of tasks specified by the count, the system judges the work.
- (b) Judge the work when the judgment signal is input to TW-800R-SCL.

Example: For the work to execute a task 2 times with the Check Pen Work flow for (a)








Use multiple receivers for one work


Since you can register up to 8 receivers for one work, the system can prevent mistakes (pokayoke) for tasks that use up to 8 tools.



When Tool sequence is set to ON, the receiver is in the standby state until the task is ready to be executed. When Tool sequence is set to OFF, the count is displayed on all receivers immediately after a work or work sequence is started.

Example: For the work to be executed in order tasks done 2 times with a torque wrench and 1 time with the Check Pen

Tool sequence settings: ON



External output (PASS/FAIL)

When multiple receivers are used for one work, PASS or FAIL outputs are generated by all receivers.

External input (Judge/Reset)


When multiple receivers are used for one work, and even when any receiver receivers an external input, the input signal will be adopted.

FAIL factors

FAIL factors consist of over-count error, remaining count error and tool sequence error. The actions of TW-800R-SCL for these errors are as follows.


Over-count error

When creating a work with POKAYOKE plus and selecting "Over-count is not permitted", executing tasks more than the specified count will be judged as Over-count.



Remaining count error


When a judgment input is received during counting, a remaining count error occurs and the FAIL output is generated.



Tool sequence error

When Tool sequence is set to ON, executing tasks in the wrong order will cause a tool sequence error.

Example) For the work to be executed in order tasks done 2 times with a torque wrench and 1 time with the Check Pen, when the task with the Check Pen is executed first.




FAIL reset method


Reset FAIL from POKAYOKE plus or the receiver. This section explains how to reset FAIL from the receiver. Select either one of the processing methods for the reset input from TW-800R-SCL in the Default settings of POKAYOKE plus.

- (a) Continue: Reset FAIL and continue the task.
- (b) Exit: Finish the work in execution.

(a) Continue task



(b) Exit task



Status	JUDGE LED	Buzzer	PASS output	FAIL output
Before the task	OFF	-	-	-
Task in progress	White	Each time a signal is received, the sound "ping" is generated.	-	-
PASS	Blue	Pi pi pi	Time until the reset timer expires	-
FAIL	Red	Pi-Pi-Pi Synchronize with JUDGE LED	-	Until FAIL is reset

5. POKAYOKE plus Viewer

By linking to the receiver without counter feature TW-8##R-EXL, the count can be displayed at up to 16 stations by locating a Windows computer with "POKAYOKE plus Viewer" at your task site.

POKAYOKE plus Viewer runs based on work execution instructions from POKAYOKE plus. POKAYOKE plus Viewer cannot accomplish the counter feature on its own. Be sure to use POKAYOKE plus Viewer along with POKAYOKE plus.

In order to use POKAYOKE plus Viewer, you must register a license of POKAYOKE plus Viewer. The instruction manual describes only license registration for POKAYOKE plus. For details of POKAYOKE plus Viewer, refer to "POKAYOKE plus Viewer Instruction manual".

License registration

POKAYOKE plus manages the license information of POKAYOKE plus Viewer. Registering the license of POKAYOKE plus Viewer to POKAYOKE plus will enable interactive communications.

To use POKAYOKE plus Viewer, you need to purchase one license for each POKAYOKE plus Viewer. When you purchase licenses, a document containing a license key*2 will be issued. Enter the license key described on the document into POKAYOKE plus.

Up to 16 licenses can be registered to one POKAYOKE plus.

When you use POKAYOKE plus Viewer for the first time or when you need to add licenses, be sure to perform license registration.

*2: <u>The document containing a license key is enclosed in the CD-ROM bag.</u> A license key is a character string in the format of "XXXXX-XXXXX-XXXXX-XXXXX".

Click "License" (1) on the menu.



Enter the issued license key in "Current license key" (2) and click "Register" button.

Make sure that the number of the purchased licenses is added to the number of POKAYOKE plus Viewer licenses (③).

6. Troubleshooting

Error messages or symptoms	Cause and remedy
Cannot know the IP address of	Click the Windows Start button, type "cmd", and press the Enter key.
the PC on which POKAYOKE	At the command prompt screen that opens, type "ipconfig" and press
plus is running.	the Enter key. The value displayed in [IPv4 Address] is the IP address
	of the PC.
Work can not be started.	The possible cause is as below:
	•The receiver or I/O unit may not be turned on. Turn ON the power
	of the receiver.
	•The tool and the receiver are not paired. For the pairing method,
	please refer to the instruction manual for the receiver.
	•The receiver or the I/O unit may have been connected with another
	POKAYOKE plus. Terminate POKAYOKE plus running on a different
	computer or delete the target receiver from different POKAYOKE
	plus.
Although workers are wearing	The possible cause is as below:
safety protectors, the alert is not	•The receiver may not be capable of receiving the signal from the
cleared.	transmitter mounted on the safety protector. When the alert is not
	cleared after changing the wearing status, check the contents of the
	notification message "The receiver cannot receive a signal from the
	transmitter".
	•The output data type of the receiver may not be set to "long data".
	To manage the wearing status of the safety protectors, you need to
	set the output data type to "Long data". For details on how to change
	the settings, see the instruction manual for the receiver.
	•When wearing safety protectors at the start of the working hours,
	an alert is generated. It may take up to 5 minutes until the alert is
	cleared.
	For details, refer to the display of the wearing status of the safety
	protectors in "3-15. Safety protectors wearing status screen".
Cannot connect to POKAYOKE	The POKAYOKE plus and POKAYOKE plus Viewer versions may
plus Viewer.	be different. Please use the same version POKAYOKE plus Viewer
	as POKAYOKE plus. The application version can be displayed by
	clicking "Product Info" in the menu.

Is one of the following messages displayed in the notification of POKAYOKE plus?

Message	Cause and remedy		
Register receiver(s) to start a	The message is displayed when no receiver is registered.		
work.	From menu, select [Register]/ [Register Receiver] and register the		
	receiver.		
	Click the message to display the receiver registration screen. The		
	message is cleared by clicking it.		
Register tool(s) to start a work.	The message is displayed when no tool is registered.		
	From menu, select [Register]/ [Register POKAYOKE Tools] and		
	register the tool.		
	Click the message to display the tool registration screen. The		
	message is cleared by clicking it.		
Register work(s) to start a work.	The message is displayed when no work is registered.		
	From menu, select [Register]/ [Tools]/[Register Work] and register		
	the work.		
	Click the message to display the work registration screen. The		
	message is cleared by clicking it.		
Connection failed.	The message is notified when connection with the receiver or I/O		
Failed to connect to TW-8##R-	unit failed or when the connection with the receiver or I/O unit is cut		
EXL (IP address	off. The possible cause is as below:		
xxx.xxx.xxx.xxx / Port No.	•The receiver or I/O unit is NOT turned ON.		
xxxxx)	•The LAN cable is disconnected.		
(The above is an example	•The receiver's IP address/Port No. is not correctly set.		
when TW-8##R-EXL is used.)	*Set the IP address so that it does not overlap in the network.		
	Click the message to display the receiver registration screen and		
	clear the message.		
Connection failed.	The message is displayed when the receiver is already connected		
TW-8##R-EXL (IP address	to different POKAYOKE plus.		
xxx.xxx.xxx.xxx /Port No.	You cannot connect POKAYOKE plus to the receiver being		
xxxxx) is connected to other	connected to different POKAYOKE plus. Perform the following		
POKAYOKE plus.	operation, and you can cut off the communication of the receiver		
(The above is an example when	with different POKAYOKE plus and connect the receiver and the		
TW-8##R-EXL is used.)	target POKAYOKE plus.		
	1.Delete the target receiver from Receiver registration of different		
	POKAYOKE plus.		
	I ONATONE plus.		

	Click the message to display the receiver registration screen and
	clear the message.
Connection failed.	The message is displayed when TW-800R-SCL is set to stand-
TW-800R-SCL (IP address	alone mode.
xxx.xxx.xxx.xxx /Port No.	When linking TW-800R-SCL to POKAYOKE plus, change the
10001) is set to "stand-alone	operating mode of TW-800R-SCL to application interlock mode.
mode". Set TW-800R-SCL to	For the setting method of the run mode, refer to "TW-800R-SCL
"application interlock mode"	Instruction manual".
when using it in this application.	Click the message to display the receiver registration screen and
	clear the message.
Cannot receive a signal from the	The message is notified when the receiver does not receive a signal
transmitter.	from the safety protector for 12 minutes or more. Please check the
Transmitter ID:0108xxxxxx	following contents.
Tool name:xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx	• Transmitter battery may be dead. Check the remaining battery
Safety protector type: Hard hats	capacity.
	•Communication distance may be too long. Install the transmitter and
	receiver in a location where they can communicate with each other.
	• Transmitter and receiver may not be paired. Check if they are
	paired.
	•Transmitter may have failed. Press the switch on the transmitter
	and check the LED lighting pattern. For lighting patterns, refer to
	"En-Guard ENS-HH01 Instruction manual".
	Click the message to clear the message.



HERUTU ELECTRONICS CORPORATION

422-1 Higashimikata-cho, Kita-ku, Hamamatsu, Shizuoka, 433-8104 Japan (Sales dept) TEL.+81-053-438-3555 FAX. +81-53-438-3411

Website URL https://www.herutu.co.jp/en/ E-mail info@herutu.co.jp